

TEMPERING REQUIREMENTS

Tempered glass (also called “safety” glass) is designed to crumble into small, rounded pieces when broken, rather than jagged shards, and is required whenever any part of a window is:

- a) within 18 inches of the floor
- b) within 24 inches of a door (unless more than 60 inches off the floor)
- c) within a shower or bath enclosure (unless more than 60 inches off the floor)